

Half Round Attachment Installation Options



Option 1

Complete assembly mounted to underbody

- Weld centerpieces to fit on the inside or outside of the longitude
- Use machine bolts in longitude to hold position and weld other end to attachment



Option 2

Assembly cut and welded

- Cut assembly and weld spring attachment to bolster
- Use center scrap piece to space assembly away from bolster when needed

For installation question's please contact one of our Tarpologist at 1-800-248-7717